



Knowing what's up!

e l e r o

Sun Shading Solutions Nice

Status LED display

of the ProLine 2 transmitter

Colour and frequency	Meaning
Flashing Orange (2 Hz)	Channel is empty or not yet programmed
Flickering Orange (20 Hz)	Channel is in bidirectional programming mode (at least one bidirectional receiver is also in programming mode)
Orange and then green	Channel is bidirectionally programmed and the receiver has received the signal.
Orange and then red	Channel is bidirectionally programmed and one of the receivers has not received the signal
Red and then green	Channel is bidirectionally programmed and the receiver has received the signal. Batteries are low!
Red and then red	Channel is bidirectionally programmed and one of the receivers has not received the signal. Batteries are low!
Green	Channel is in unidirectional mode
Orange and green alternating, then red	Channel (transmitter) is deleted
Red flashing	Batteries are low!



elero GmbH
Maybachstr. 30
72660 Beuren
Germany
P +49 7025 13-01
F +49 7025 13-209
E info@elero.de

www.elero.com

ProLine 2

Bidirectional transmitter programming

Function	Button combination	Procedure	Condition/prerequisite
Interrupt supply voltage: Switch circuit breaker off/on			
Start preparation to programming mode (time: 5 min.)	▲ + ▼ + ●P	Press for approx. 3 sec.	Transmitter already programmed
	▲ + ● + ▼ + ●P	Press for approx. 6 sec. (until LED lights up red)	Transmitter already programmed (all receivers that know the transmitter are now deleted)
Start (synchronous*) programming mode (progr. time: 2 min.)	●P	Press for approx 1 sec. on the transmitter to be programmed until LED lights up orange	Receiver in (synchronous) programming mode
Stop programming mode (in transmitter + receiver)	●	Press for approx. 6 sec. (until LED flashes orange)	Programming mode was started with this transmitter
Stop programming mode	●	Tap	Transmitter already programmed
Start learning readiness synchronous* mode (time: 5 min.)	▼ + ●P	approx. 3 sec. -> LED lights up orange	Transmitter already programmed
Start (synchronous*) programming mode (progr. time: 2 min.)	●P	approx. 1 sec. -> LED lights up orange	Receiver in programming mode
Programme transmitter	▲ + ▼	Briefly press UP button immediately after the start of any 'upward movement' (drive stops briefly) and briefly press DOWN button after the start of any 'downward movement'. The drive stops	Transmitter and receiver are in programming mode / the blind constantly drives UP and DOWN for a short distance!
Delete an individual transmitter/channel from the receiver	●P + ●	approx. 6 sec. -> LED lights up red	Transmitter already programmed
Delete EVERYTHING from the receiver	▲ + ● + ▼ + ●P	approx. 6 sec. -> LED lights up red	Transmitter already programmed
Programme intermediate position	▼ + ●	Press and hold the DOWN button until the desired position is reached, then additionally press the STOP	Transmitter already programmed
Delete intermediate position	● + ▼	approx. 3 sec. -> LED goes off briefly	Transmitter already programmed
Drive to intermediate position	2x ▼	Quickly push DOWN button 2x	Intermediate position already programmed
Programme ventilation or tilting position	▲ + ●	Press and hold the UP button until the desired position is reached, then additionally press the STOP button briefly	Transmitter already programmed
Delete ventilation or tilting position	● + ▲	approx. 3 sec. -> LED goes off briefly	Transmitter already programmed
Drive to tilting position	2x ▲	Quickly push UP button 2x	Intermediate position already programmed

* The UP and DOWN drives of the receiver (from date of manufacture 06/05) start synchronously. The simultaneous programming of a transmitter on several blinds is thus possible.

Explanation of the push buttons on the example of the LumeroTel 2 hand-held transmitter

