






Function	Buttons to press	Procedure	Condition/ prerequisite
Programme ventilation or tilting position	1. 	Press and hold the UP button until the desired position is reached, then <u>additionally</u> press the STOP button briefly (< 2 Sek.)	Transmitter already programmed
	2. 		
Delete ventilation or tilting position		approx. 3 sec. → LED goes off briefly	Transmitter already programmed
Drive to tilting position	2x 	Quickly push UP button 2x	Tilting position already programmed

Explanation of the push buttons on the example of the LumeroTel 2 hand-held transmitter:

Front



Back



elero Profi Guide

Status LED display of the ProLine 2 transmitter



Wissen was läuft!
Knowing what's up!

Colour/frequency	Meaning
Flashing Orange (5 Hz)	Channel is empty or not yet programmed
Flickering Orange (10 Hz)	Channel is in bidirectional programming mode (at least one bidirectional receiver is also in programming mode)
Orange and then green	Channel is bidirectionally programmed and the receiver has received the signal
Orange and then red	Channel is bidirectionally programmed and one of the receivers has not received the signal
Red and then green	Channel is bidirectionally programmed and the receiver has received the signal. Batteries are low!
Red and then red	Channel is bidirectionally programmed and one of the receivers has not received the signal. Batteries are low!
Green	Channel is in unidirectional mode
Orange and green alternating, then red	Channel (transmitter) is deleted
Red flashing	Batteries are low!

11/13

elero GmbH
Maybachstr. 30
73278 Schlierbach/Germany
T +49 7021 9539-0
F +49 7021 9539-209
E info@elero.de





www.elero.com





elero Profi Guide 1

ProLine 2









Bidirectional transmitter programming

Function	Buttons to press	Procedure	Condition/ prerequisite
Start learning readiness mode (time: 5 min.)	Interrupt supply voltage: Switch circuit breaker off/on		
		approx. 3 sec.	Transmitter already programmed
		approx. 6 sec. → LED lights up red	Transmitter already programmed (all receivers that know the transmitter are now deleted)
Start learning readiness synchronous* mode (time: 5 min.)		approx. 3 sec. → LED lights up orange	Transmitter already programmed
Start (synchronous*) programming mode (progr. time: 2 min.)		approx. 1 sec. → LED lights up orange	Receiver in programming mode

Function	Buttons to press	Procedure	Condition/ prerequisite
Stop programming mode (in transmitter & receiver)		approx. 6 sec. → LED lights up orange	Programming mode was started with this transmitter
Stop programming mode		Tap	Transmitter already programmed
Programme transmitter	<div>1. </div> <div>2. </div>	Briefly press UP button immediately after the start of any 'upward movement' (drive stops briefly) and briefly press DOWN button after the start of any 'downward movement'. The drive stops	Transmitter and receiver are in programming mode and the blind constantly drives UP and DOWN for a short distance!

* The drives move UP and DOWN synchronously during programming. The simultaneous programming of a transmitter on several blinds is thus possible (from date of manufacture 06/05).

Function	Buttons to press	Procedure	Condition/ prerequisite
Delete an individual transmitter/channel from the receiver		approx. 6 sec. → LED lights up red	Transmitter already programmed
Delete EVERYTHING from the receiver. Reset transmitter channel		approx. 6 sec. → LED lights up red	Transmitter already programmed
Programme intermediate position	<div>1. </div> <div>2. </div>	Press and hold the DOWN button until the desired position is reached, then <u>additionally</u> press the STOP button briefly (<2 Sek.)	Transmitter already programmed
Delete intermediate position		approx. 3 sec. → LED goes off briefly	Transmitter already programmed
Drive to intermediate position	2x 	Quickly push DOWN button 2x	Intermediate position already programmed